



AUTOMATIC SLIDING DOORS

SPARE PARTS LIST

<p>Drive Unit</p> 	<p>Control Unit</p> 	<p>Radar (Eagle 6)</p> 	<p>PSA Control Panel</p> 
<p>Supporting Beam</p> 	<p>Carriage Wheel</p> 	<p>Belt Clamp</p> 	<p>Toothed Belt</p> 
<p>Reserve Wheel</p> 	<p>Nylon Track Rail</p> 	<p>Double Drive</p> 	<p>Electro-Mechanical Locking</p> 
<p>Electric Plug Lock</p> 	<p>Stopping Device</p> 	<p>Radar KSS-1M</p> 	<p>Key Switch</p> 
<p>Safety Beam</p> 	<p>Backup Battery</p> 	<p>Operator Cover</p> 	